



Step 1

Mark the hole locations by aligning the wire rack to the wall



Step 2

Drill the areas you marked.



Step 3

Install the dowels.



Step 4

Screw the wooden shelves into the screw slots on the wire



Step 5

Hang the rack you prepared into the wall dowels by screwing.